

No Flush BioClean™ Concentrate is specially formulated to maintain low water use urinal systems.

How it Works.

No Flush BioClean™ Concentrate works together with the No Flush BioSleeve™ to help eradicate odours and staining in and around the urinal. The millions of micro-organisms work at degrading the lime-scale and uric salt deposits often found on the urinal surface, the areas surrounding the urinal and in the waste outlets.

Where to Use It.

No Flush BioClean™ Concentrate can be used on and around both trough type urinals and single ceramic models.

Use the diluted No Flush BioClean™ on surfaces in the washroom that come into contact with urine.



How to Use It.

No Flush BioClean™ is a concentrate and needs to be diluted before use.

Dilution ratios differ depending on the application and the situation.

Situation	Ratio	Per litre of water
Standard/daily cleaning	20:1	50ml
Heavily Soiled/used	10:1	100ml
Remedial Clean	5:1	200ml

Standard cleaning is performed daily to remove any material from the face and surrounds of the urinal. Simply spray the diluted No Flush BioClean™ over the face of the urinal and its immediate surrounds. Wipe the areas sprayed with a cloth to remove soil, re-spray and leave to dry.

Heavily soiled or high use urinals may need a slightly stronger concentration but the cleaning method is exactly the same as above.

Remedial Cleaning is performed where the urinal and surrounds have built up deposits that need extra time and attention to remove. Mix a stronger solution and thoroughly saturate stubborn deposits. Leave this for a few minutes and scrub, re-spray and leave overnight, scrub and rinse again.

Contact No Flush Solutions for MSDS.